

XL2 PROJECTOR PRO



FEATURES:

- **XL2 Projector PRO** software is a free download for all registered XL2 customers with Windows 7, 8, 10 or higher or Mac OS 10.8 or higher.
- **XL2 Projector PRO** allows XL2 screen to be viewed in real-time on a tablet or computer connected via USB. Optional “XL View” and “Sound Level Predictor” display extend XL2 Projector PRO for live sound monitoring.
- Ability to retrieve measurement data from XL2 without interruption to the measurement process.
- Projector PRO settings can be saved in software profile. For daily event monitoring, the sound level monitoring starts automatically when the computer starts up and ends when shutdown. The XL2 Sound Level Meter stores the measurement data for later documentation.
- The time of XL2 sound level meter is automatically synchronized with the computer time for precise recording.
- **Option “XL View”:** “XL View” allow up to 3 sound pressure levels to be displayed in on the computer screen. Exceeding levels are presented with a pre-warning amber or alarming red in color. To access the “XL View”, a Projector PRO Option must be installed on the XL2 Sound Level Meter.
- **Option “Sound Level Predictor”:** “Sound Level Predictor” visualizes the level history of the current measurement interval and indicates the headroom for the actual measurement period or the next few minutes. Green bars confirm the present level is well below limits while red bars are an indication to reduce the sound level. To access the Sound Level Predictor, a Projector PRO Option must be installed on the XL2 Sound Level Meter.

Firmware Version Requirement	XL View, Virtual XL2 Keypad	Sound Level Predictor	Internal File Viewer	Profiles
V2.30 or higher	X	NA	NA	NA
V3.10 or higher	X	X	NA	NA
V3.22 or higher	X	X	X	NA
V4.00 or higher	X	X	X	X